

PRODUCT: PURGE Spa Bath Pipe Degreaser

DATE OF ISSUE: July, 2019

Company: HY.GIENE Australia Pty Ltd

Address: Unit 3, 41 Gatwick Rd, Bayswater North Vic, 3153 Australia

Telephone: +61 3 9729 3946 Email: sales@hygieneaustralia.com.au



1. PRODUCT DESCRIPTION/APPLICATION

PURGE is used when the spa bath shows a residual of brown foreign matter on the water surface.

When extra dosing with **SPA.GIENE** fails to eliminate the problem, **PURGE** can be applied using strict guidelines

COMMON CAUSE

Residue is caused from the spa bath not being flushed clean after every use or by incorrect dosage and the buildup of body fat has become too much for SPA.GIENE to break down and dislodge on its own.

The increasing use of body oils, tanning spray, make-up, body soaps and inadequate protocol when it comes to cleaning spa baths, will contribute to a never ending buildup of foreign matter which harbours the nasty bacteria's in the pipework, pump and jets.

We do not recommend the use of chlorine or acid-based chemicals to flush the foreign matter from spa pipes.

2. METHOD OF USE

Cleaning protocol: Fortnightly - Monthly preventative maintenance program

Part A Daily until residue is removed

- Fill the spa bath with hot water and add 1L PURGE per 200L of water.
- Turn on spa and run for 10 minutes turning off and on at different intervals to help agitate the foreign matter that has built up, from the pipes.
- Empty the spa and rinse with water whilst wiping away any excess residual that is left in the bath
- Fill and run for 3-5 minutes to flush out any residue

Part B

- Fill SPA.GIENE spray bottle with SPA.GIENE concentrate. Spray into all jets and around the jet cover area, plug drain area and any other cracks and crevices where bacteria harbors. Scrub into and around these areas, allow a few minutes to dwell, then thoroughly rinse with clean water
- Remove the suction cover and remove or clean opening area including suction cover
- Fill the bath with fresh hot water
- Add 50ml SPA.GIENE then turn on the spa and run for 3-5 minutes.
- Empty the spa and rinse with water whilst wiping away any excess residual that is left in the bath with a clean cloth. Do not use dirty (used) cloths when wiping out the spa bath).

Flush cleaning after every checkout - and regularly during extended room stay of 3+ days

- Ensure the bath is filled 3-4 cm above the highest jet – hot/warm water.
- The pump only needs to be on for **maximum** 5 minutes
- Rinse clean with water – do not wipe bath out with contaminated cloths

Do not use any other cleaning product in the bath area. Spray and wipe cleaning can only be done using SPA.GIENE Spray & Wipe.

3. TECHNICAL DETAILS

PURGE is 100% biodegradable

4. PACKAGING

Product Code	Size
20135	5L
20136	15L

5. CLASSIFICATION & SAFETY

PURGE must be used with care. Store in a secure area. Wear safety glasses and impervious gloves when changing drums. Safety Data Sheets are available on all HY.GIENE AUSTRALIA products.

Please make sure the current issue is available and read before using the product.