



# **PURGING SPA BATHS**

PURGE is used when the spa bath shows a residual of brown foreign matter on the water surface.

When extra dosing with **SPA.GIENE** fails to eliminate the problem, **PURGE** can be applied using strict guidelines

## **COMMON CAUSE**

Residue is caused from the spa bath not being flushed clean after every use or by incorrect dosage and the buildup of body fat has become too much for SPA.GIENE to break down and dislodge on its own.

The increasing use of body oils, tanning spray, make-up, body soaps and inadequate protocol when it comes to cleaning spa baths, will contribute to a never ending buildup of foreign matter which harbours the nasty bacteria's in the pipework, pump and jets.

We do not recommend the use of chlorine or acid-based chemicals to flush the foreign matter from spa pipes.

## **APPLICATION**

### **Cleaning protocol: Fortnightly - Monthly preventative maintenance program**

#### **Part A** Daily until residue is removed

- Fill the spa bath with hot water and add 1L PURGE
- Turn on spa and run for 10-15 minutes turning off and on at different intervals to help agitate the foreign matter that has built up, from the pipes.
- Empty the spa and rinse with water whilst wiping away any excess residual that is left in the bath
- Fill and run for 3-5 minutes to flush out any residue

#### **Part B**

- Fill SPA.GIENE spray bottle with SPA.GIENE concentrate. Spray into all jets and around the jet cover area, plug drain area and any other cracks and crevices where bacteria harbors. Scrub into and around these areas, allow a few minutes to dwell, then thoroughly rinse with clean water
- Remove the suction cover and remove or clean opening area including suction cover
- Fill the bath with fresh hot water
- Add 50ml (per 200L water) SPA.GIENE then turn on the spa and run for 3-5 minutes.
- Empty the spa and rinse with water whilst wiping away any excess residual that is left in the bath with a clean cloth. Do not use dirty (used) cloths when wiping out the spa bath).

### **Flush cleaning after every checkout - and regularly during extended room stay of 3+ days**

- Ensure the bath is filled 3-4 cm above the highest jet – hot/warm water.
- The pump only needs to be on for **maximum** 5 minutes
- Rinse clean with water – do not wipe bath out with contaminated cloths

Do not use any other cleaning product in the bath area. Spray and wipe cleaning can only be done using **SPA.GIENE** Spray & Wipe.