PRODUCT INFORMATION SHEET ULTRA COMBI OVEN CLEANER

DATE OF ISSUE: JANUARY 2019



Company: HY.GIENE Australia Pty Ltd

Address: Unit 3, 41 Gatwick Rd, Bayswater North Vic 3153 Australia **Telephone:** (03) 9 729 3946 Email: sales@hygieneaustralia.com.au

1. SPECIAL FEATURES

ULTRA COMBI OVEN CLEANER is a fast-acting detergent for removing fat, grease, carbon and food residues from combination steamer ovens.

ULTRA COMBI OVEN CLEANER is formulated for cleaning the inside and outside surfaces of combi steamer ovens. Also suitable for cleaning other ovens, grills and hotplates.

2. DESCRIPTION

ULTRA COMBI OVEN CLEANER is a colourless and odurless transparent alkaline liquid detergent with ingredients to dissolve and emulsify the oils and fats as well as saponifying fats (potassium hydroxide). It is a water-based detergent. The hydroxide level is set at the correct concentration to prevent any attack of the seals in combi-ovens.

Dangerous Good Classification:

UN NO. 1719	Class: 8
PACK GRP: 11	HAZCHEM: 2R
pH 13-13.5	Corrossive liquid (Caustic Alkali

3. DIRECTIONS FOR USE

Do not apply ULTRA COMBI-OVEN CLEANER to aluminium or painted surfaces.

COMBI-OVENS:

- 1. Switch off COMBI-OVEN and allow it to cool down slightly (it must be less than 80 C).
- 2. Spray or brush ULTRA COMBI-OVEN CLEANER onto internal surfaces.
- 3. Let soak for five minutes.
- 4. Wipe with a cloth, sponge or pad to help product break down residue.
- 5. Remove all residue by wiping up with a damp cloth.
- 6. Rinse surfaces with clean water.

Convection ovens

Pre heat oven to 60 C then turn off. Apply neat ULTRA COMBI-OVEN CLEANER onto surfaces and leave for five minutes to activate. Loosen carbon residues with a stiff brush or scraper. Wipe up dissolved solids with a damp cloth then rinse thoroughly with clean water.

Grills & Hot Plates

Turn hotplate off after use and allow to cool for 5 minutes. Surface should be warm but not at full heat. Scrape food residues off then apply neat ULTRA COMBI-OVEN CLEANER. Leave wet to activate for 10 – 15 minutes. Scrub with brush, spatula or griddle pad then wipe clean with cloth.

- Rinse well with potable water. Brush surface with cooking oil.
- Do not use on very hot surfaces as irritating vapours will be produced.
- Do not spray around food. Remove food from the area and store safely.
- Do not spray anything on the air intakes of the oven.
- The hand shower may be used to clean inside the COMBI-OVEN but not for the outside.
- Clean the outside of the COMBI-OVEN manually.
- Wear safety glasses and gloves when using ULTRA COMBI-OVEN CLEANER. See the Safety Data Sheet for more details.

4. HEALTH AND SAFETY

HAND & SKIN CARE:

After washing, rinse and dry hands thoroughly. People with sensitive skin should avoid prolonged contact with the washing solutions or should wear protective gloves.

Safety Phrases:

S(1/2) – Keep locked up and out of reach of children. S50 – Do not mix with acids.

S26 - In case of contact with eyes, rinse immediately with plenty of water and seek medical advice. S28 - After contact with skin, wash immediately with plenty of soap-suds.

S37/39 - Wear suitable gloves and eye/face protection

S45 - In case of accident or if you feel unwell, seek medical advice immediately (show the label whenever possible).

FIRST AID:

If poisoning occurs, contact a doctor or Poisons Information Centre (phone 131126). For more information, the Safety data Sheet is available for this product.

5. PACKAGING

5L Polyethylene DG Bottle

6. ENVIRONMENTAL CARE

ULTRA COMBI-OVEN CLEANER conforms to all statutory environmental requirements. It is based on safe ingredients selected to perform efficiently so there is no waste or damage. ULTRA COMBI-OVEN CLEANER is non-flammable and based on biodegradable surfactants. ULTRA COMBI-OVEN CLEANER containers will be cleaned and reused if returned to HY.GIENE AUSTRALIA Pty Ltd., significantly reducing plastic usage and waste. They can also be recycled.